


SOKANY[®]

Hand-held vacuum cleaner an instruction manual



SK-3377

220V-240V 50-60HZ 2000W

**Note: When the suction power decreases or the sound increases,
clean the front and back sides of the Hypa in time**

◆ Product structure chart




Figure 1

Remarks: the style of each small accessory and brush shall be subject to the real thing

◆ Product assembly

1. Install the floor brush assembly: as shown in Figure 2, install the straight pipe assembly into the floor brush assembly. After installation, as shown in Figure 3.




Figure 2




Figure 3

2. Install the host assembly: As shown in Figure 4, install the straight pipe floor brush assembly into the host assembly and lock it. After installation, the state is shown in Figure 5.




Figure 4



Figure 5

◆ Product components

3. The usage of various accessories is shown in the figure below, select the required accessories to connect.



4. All the parts installed in the front can be disassembled. The method is to press and hold the corresponding lock button and pull out the components to both ends. When pulling it out too tightly, you can squeeze it inward and then pull it in the opposite direction. (The styles of small accessories and floor brushes are subject to the actual product)

◆ Clean up the garbage in the dust cup

When the machine is used, the garbage will accumulate in the dust cup. At this time, it should be cleaned up in time. The method is: press and hold the dust cup lock to make it bounce off the dust cup cover, and let the dust cup cover open. As shown in Figure 6, pour out the internal trash into the trash can. After cleaning, lock the lid of the dust cup and you can use it again. It is recommended to clean up the rubbish after each use!




Figure 6

Note: When the suction power decreases or the sound increases, clean the front and back sides of the Hypa in time

◆ Filter system disassembly and washing




Figure 7




Figure 8




Figure 9

Operation method:

As shown in Figure 7

Dismantling: Hold the lock button on the pipe with your left hand and pull it out, hold the dust bucket with your right hand and lift it up to separate the dust bucket from the host.

Packing: Hold the dust bucket with your left hand and the host with your right hand. Align the protrusion of the upper end of the dust bucket with the arrow on the host to coincide with it, and then press the dust bucket down. Note: Don't forget to install the sealing strip, the filter sea PA must be installed flat!

☆It is recommended to clean the front and back sides of the HyPa and the filter every time you clean up the garbage. (If there is optional filter cotton, please clean it in time)

☆Special reminder: Only the dust cup and the inner parts of the dust cup can be cleaned, and the rest is forbidden to clean!!!

◆ Machine operation instructions:

- 1、 Before using the machine for the first time, please confirm that the dust cup and Haipa have been installed.
- 2、 Plug in the power and turn on the power switch.

◆ Precautions:

1. Please read this manual carefully before use, and keep it for future use after reading.
2. When using, please make sure that the power supply meets the requirements.
3. Please make sure that the plug and hands are kept dry to avoid the risk of electric shock.
4. Do not use this machine to absorb inflammable and explosive materials or flames that have not been completely extinguished, such as ashes, cigarette butts, matches, etc.
5. Do not use this machine to absorb water and any other liquids, glass and metal fragments, etc.
6. Except for the dust-removing cup assembly of this machine, any other parts can not be washed with water or directly immersed in water.
7. Do not disassemble, repair or modify internal parts by yourself.
8. This vacuum cleaner is for household use only, please do not use it in business premises. It is forbidden to suck up decoration garbage.
9. If the power cord is damaged, it needs special tools, so it must be replaced by the maintenance point designated by the manufacturer. Users are not allowed to replace it by themselves.
10. Please use original parts for maintenance service. Our company is not responsible for arbitrarily replacing non-factory parts.
11. In the following situations, please stop using it immediately and send it to the dealer or contact the service line for processing.
 - ☆ Other parts except the dust removal cup are dropped into water or soaked in other liquids.
 - ☆ The circuit is short-circuited, sparks or smoke appear.
 - ☆ Damaged by collision or fall.